



## LED Beacon GS-2000B

Using high-capacity battery CR123 as power, built-in IC chip control LED flash, this light has 9 user selectable flash patterns: ROTATE, double blink, single blink, alternative, SOS (Morse code) for rescue, solid-on (high), solid-on (low), 2 LED flashlight and 4 LED flashlight.

### Easy to use!

Press the button located on the face of the light, directly above metal circle, to cycle through its nine flash/lighting functions. Pressing the button in 2 seconds, the light is off, and press again, the light patterns is still on that pattern.

- Compact & visible up to a 1/2 mile away.
- Contains a strong magnet for placement on vehicle
- Can be deployed on the ground and roadway.
- Casing is constructed of ultra high strength plastic and is able to withstand a drive over by a sedan car.
- Completely waterproof
- Floats on water! Perfect for boats and watercraft safety, also it is no problem working underwater 1/2 miles.
- Standard red LED is perfect for clear weather.
- In foggy conditions the yellow and blue LED provide superior visibility.
- Powered by a high capacity CR123 lithium battery with a storage life up to 10 years.
- Store temperature from -40C to + 60C.
- Suitable for HAZMAT applications
- Dimensions: Diameter 10. 8cm, Height 3.5cm
- Product weight: 290g
- Number of LED's: 16



### Flash patterns and running time

| Pattern                        | Run Time |
|--------------------------------|----------|
| Rotate:                        | 15 Hours |
| Quad Flash:                    | 15 Hours |
| Single Blink:                  | 60 Hours |
| Alternate:                     | 15 Hours |
| S.O.S and Rescue (Morse Code): | 24 Hours |
| Solid-On-High:                 | 8 Hours  |
| Solid-On-Low:                  | 45 Hours |
| 2 LED Flashlight:              | 15 Hours |
| 4 LED Flashlight:              | 10 Hours |

\*Specifications are subject to change without prior notice.